QUICK START GUIDE


© element



WHAT'S INCLUDED



Your new TV!



TV Stand

Stand Screws



Remote





2 AAA Remote Batteries



WE'RE HERE TO HELP

Find resources and get help with product setup, connecting devices, technical issues, downloading manuals and more!

We're available 24 hours a day, 7 days a week



elementelectronics.com



1.888.842.3577




customerservice@elementelectronics.com

We recommend keeping your TV box for the duration of your warranty. See your product warranty for details.

CONNECT DEVICES TO YOUR TV

Check to ensure that you have selected the right cables for the ports and that they are connected securely (cables and external devices not included). Loose connections can affect your picture and audio quality. Actual connections may vary by model. Please refer to the actual product.






CONNECT DEVICES TO YOUR TV


(continued)

composite (good quality)



Connect a composite video (yellow) or component video (green/blue/red) and left-right audio cables from an external AV device.

component (better quality)



Installing the stands

Do not install the stands if you want to wall mount your TV. See your wall mount instructions for mount installation details.

You will need: Phillips screwdriver (not included)

- **1.** Place the TV screen-down on a clean, flat, soft surface (e.g.: blanket) to prevent scratches or damage to the screen.
- 2. Use a Phillips screwdriver to attach each stand with the provided screws.
- **3.** Place the TV upright on a stable, level surface.



(continued)



Place batteries in remote


Power your TV remote by inserting the included batteries carefully matching (+) and (-) indicated inside the batterycompartment.

TIP: Always replace dead batteries with two brand-new batteries from the same manufacturer. Never use damaged batteries.

If your remote gets warm/hot during use, discontinue use and contact customer support immediately.



(continued)





Plug in and turn on TV

Plug your TV into the wall outlet and press the power button on your remote control.



(continued)



Press the ▼▲◀▶ buttons on your remote to select or change a setting. When you're finished, press MENU to exit the Setup Wizard.

Menu Language: Select the language you want to be displayed in the menu. The default language is English.

Time: Select the time zone and daylight saving time.

Air/Cable: Select whether you want to watch TV with an antenna (Air) or through a cable/satellite box (Cable).

Auto Scan: Search and store available channels automatically.



LET'S REGISTER YOUR PRODUCT



It's super easy, just head on over to elementelectronics.com/register

BENEFITS OF REGISTERING YOUR PRODUCT:



Support

Get assistance quickly by pre-registering your product.



News & Offers

Take advantage of the latest news and special offers from Element.



Updates

Stay current with important product updates and notifications.



Warranty

Receive a 2-year limited warranty with registration.*

*1-year manufacturer's limited warranty with purchase, or 2-year limited warranty with product registration within 90 days of purchase. See warranty card for details.



QUICK START GUIDE



Element, the Element Logo, and Bring it home are trademarks of Element Brand Holding, LLC. ©2023, Element Brand Holding, LLC, All Rights Reserved.